



How to load Flash Player to Cloud TV Box STB370?

Due to the always evolving video formats in the internet, sometimes you may see prompt on the TV screen to ask you to add or to load Flash Player, for example, the prompt can be "This content required Adobe Flash Player-Version 10.2.159".


In this situation, please go to a browser window, then, click on the vertical three dots on the upper right corner.




Click on "Settings",




Click on "Advanced",



Click on "UAString",



Shift between "Android" and "Desktop",



Then click return to go back to the browser page, refresh, and you can watch the content now.